

Please read these instructions carefully. See hardware and furniture parts list for guidance.
Ensure that all parts are accounted for before assembly.
Place all wooden parts on a clean, smooth surface to prevent scratching.
Follow the below steps to begin assembly.


- CAUTIONS: 1. Do not FULLY- TIGHTEN the nut or bolt until all nut and bolt is ready to be assembled.
2. Do not OVER - TIGHTEN the nut or bolt avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.


PART LIST		
ITEM	DESCRIPTION	QTY
A	BENCH TOP WITH SEAT	1 PC
B	BENCH LEG	2 PCS
C	APRON	2 PCS
D	CENTRE SUPPORT	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	WOOD DOWEL M8 x 30mm	6 PCS
2	JCBC BOLT M6 x 40mm	2 PCS
3	JCBC BOLT M6 x 50mm	4 PCS
4	SPRING WASHER M6	6 PCS
5	FLAT WASHER M6 x 13mm	6 PCS
6	CSK SCREW M4 x 32mm	24 PCS
7	WOOD BUTTON 14.5mm	2 PCS
8	ALLEN KEY M4	1 PC


STEP 01




STEP 02





STEP 03




STEP 04




STEP 05



STEP 06



STEP 07



FULLY SET-UP (BENCH CHAIR)