









Assembly Manual

PART LIST

| | | | | |
|--|--|---|---|---|
|  |  |  |  |  |
| A | B | C | D | E |
| 1 PC | 2PCS | 4 PCS | 4 PCS | 1 PC |



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.